

MEGAWall®

SLATWALL SYSTEMS

Prior to the installation of MegaWall, install 1/2" Plywood Sheathing from floor to 11'6" AFF


A. Measure 4" down from the top of desired slatwall panel. Laser or snap a level line.

B. Place first profile above the line and screw into the plywood at every 8"-10" on center.

C. Insert the next profile into the bottom of the first profile. Screw at every 8"-10" and repeat until you reach the bottom of the wall.


MegaWall recommends using anchor bolt when applying to substrate if a stud is not available at the end of profile.

Caution: Improper installation will cause accessory problems and uneven walls.



No Gap.

Correct Interlock




Gap.

Incorrect Interlock


Trim

Install trim with self tapping screws, pop-rivets or construction adhesive for additional adhesion.




~~Top Trim~~ Not used

1-1/4" front face x 3/4" top and 1/4" back. Back fold hooks over a top slat.



~~Bottom Trim~~ Not used

1-1/4" front face x 3/4" bottom.



End Trim

3/4" x 3/4" to cover exposed side edges.



Inside/Outside Corner Trim

1-1/4" x 1-1/4". Same piece functions for inside and outside corners.

3" Steel Installation Instructions

MegaWall Steel Slatwall uses individual slat profiles that interlock and screw to a wall to create slatwall sections.

