

ATTENTION: PLEASE READ ENTIRE INSTRUCTIONS BEFORE BEGINNING.

### Components Suggested



- Heavy Duty Construction Adhesive (We Recommend: Loctite PL375)
- Caulking Gun (if necessary)
- Trowel
- Putty Knife

### Step 1

Apply adhesive to the panel with a trowel.  
Spread evenly over the entire surface.  
Apply adhesive to the wall with a trowel.  
spread evenly over the entire surface.



### Step 2

Apply panel to backerboard  
on the wall. See image below.



### Step 3

Apply pressure to panel until adhesive has set. (see image below)  
Remove any excess glue from edges.

